

Radio Pull Cord

Introduction

Pullcords should be strategically placed around the home to provide an easy means for the user to activate an emergency alarm call. They will normally be fitted in rooms where personal pendants may not be worn, e.g. in the bathroom or alongside the bed. Pullcords should be ceiling mounted - they are not suitable for wall mounting.

Being wireless, they can be used to speed-up the installation in a home where it would otherwise be difficult or time consuming to hard-wire a standard pull cord.

Emergency Alarm Calls can be made by simply pulling the cord once - no further action is required.



Features and Benefits

- Manually activated fixed trigger device.
- Ceiling mounted momentary action switch.
- Anti-ligature safety break.
- Digital Heartbeat.
- Bi-directional TAO technology.
- Daily battery self test and low battery reporting.
- 2.7 metre long orange cord.
- 2 Triangular orange grips.

Compatibility

Compatible with TAO compatible alarm receivers

Reach IP	Carer Response	Advent XT2 Digital Grouped Living Solutions
----------	----------------	---

Legrand Assisted Living and Healthcare

Blyth Workspace, Commissioners Quay, Quay Road, Blyth, Northumberland NE24 3AF.

Tel: 01670 352 371 | Fax: 01670 362 807 | Email: sales@tynetec.co.uk | Web: www.tynetec.co.uk

Registered Office: Great King Street North, Birmingham, B19 2LF | Registered in England No. 00115834

Version No.1 Radio Pull Cord. 10/19

Specification

Power	Up to 5 years Battery Life (Typical)
Conformity	CE Marked
Standards	Compliant with the following standards: - Electromagnetic Compatibility (EMC) Emissions & Immunity Standards: - EN 61000-6-3:2007+A1:2011 - EN 50130-4:2011+A11:2014 - Radio Equipment Directive: ETSI EN 300 220-3-1 V2.1.1 (2016-12) - Social Alarm System Standard: EN 50134-3:2012
Telecare Transceiver	869.2125MHz Class 1.5
Operating Temperature	+5°C to +40°C
Warranty	2 years

Dimensions

Dimensions	87mm diameter x 35mm (d)
Weight	85 grams

Product Codes

- ZXT820** - Radio Pull Cord

Spares

- E10230** - Replacement Pullcord

As our policy is one of constant product improvement the right is therefore reserved to modify product specifications without prior notice.

Legrand Assisted Living and Healthcare

Blyth Workspace, Commissioners Quay, Quay Road, Blyth, Northumberland NE24 3AF.

Tel: **01670 352 371** | Fax: **01670 362 807** | Email: sales@tynetec.co.uk | Web: www.tynetec.co.uk

Registered Office: Great King Street North, Birmingham, B19 2LF | Registered in England No. 00115834

Version No.1 Radio Pull Cord. 10/19